

Pontiac Sunfire | 1995-1999 Car Radio Removal



STEP 1:

To remove the radio the plastic dash panel surrounding the radio must be removed. Open the glove box. Locate and remove two (2) phillips screws that are hidden behind the glove box door that secures the right side of the plastic dash panel.



STEP 2:

Once the screws have been removed, the entire plastic dash panel can be pulled from the main dash assembly. The best place to start is the top right corner above the radio. With your hands, pull the dash until it begins to separate from the main dash assembly. The left side of the plastic dash panel is simply attached to the dash with male tabs that slide into rubber female plugs located on the side of the plastic dash panel below the steering wheel. Once the right side of the plastic dash panel has been freed, slide the plastic dash panel to the right so that the male tabs on the left side separated from the female plugs.



STEP 3:

Pull the plastic dash panel away from the dash. The radio should now be exposed. Locate and remove two (2) 7 mm bolt screws that secure the metal brackets attached to the radio.

Pull the radio out of the dash. Unplug the black cable plugged into the rear of the radio. Unplug the plastic connector plugged into the rear of the radio.