

## Chrysler Town & Country | 1996-1999 Car Radio Removal



**STEP 1:**

Locate and remove two (2) **Phillips screws** securing the top of the radio dash panel.

Open ash tray / coin tray below radio.  
Unsnap the narrow plastic piece that is attached between the lower edge of the radio dash panel and the ash tray assembly.



**STEP 2:**

Locate and remove (2) **Phillips screws** securing the bottom of the radio dash panel which were hidden behind the narrow plastic piece removed in step 1.

Radio dash panel is now free to be removed.  
Pull gently to release the panel from the main dash assembly.



**STEP 3:**

The radio is held in with (2) two **10 mm bolts**. Remove both to free the radio. Unplug the antenna wire and (2) two dash wire harness connectors that snap into the rear of the radio. A metal braid ground strap secured to the back of the radio with (1) one **10 mm bolt** must be removed. The radio is now free to be completely removed from the dash.