

# Nissan 200 SX | 1997-2000

## Car Radio Removal



### STEP 1:

With a small flat head screwdriver or a small sharp pointed tool unsnap the plastic cover located between the hazard switch and the defrost switch.

Behind the cover will be one (1) phillips screw. Remove the screw.



### STEP 2:

With the same small flat head screwdriver or sharp pointed tool, insert the tip between one of the top corners of the plastic dash panel and the soft body of the main dash. Gently pry the plastic panel until you can reach your fingers behind the plastic dash panel. Pull the top of the plastic dash panel until it unsnaps from the body of the main dash.



### STEP 3:

Pull the bottom of the plastic dash panel until it unsnaps from the body of the main dash.



### STEP 4:

Once the plastic dash panel has been completely unsnapped from the dash, you will notice connectors attached to the rear of both the hazard switch and defrost switch. Unplug both connectors and the plastic dash panel can be completely removed from the body of the main dash.



### STEP 5:

Once the plastic dash panel has been pulled off, the screws securing each side of the radio should be visible. Locate and remove four (4) phillips screws, (2) screws on each side of the radio. The radio and pocket are attached on each side with metal brackets. When you remove the (4) screws, the radio will pull out with the pocket attached.



### STEP 6:

Unplug the antenna cable from the rear of the radio. Unplug 2 white connectors plugged into the rear of the radio. Pull the radio/pocket assembly completely from the dash.