

Chevy Impala | 1994-1996

Car Radio Removal



NOTE:

In order to remove the radio, the entire lower dash panel must be removed in order to gain access to the screws that secure the radio. As seen in the photo above, the plastic dash surrounding the radio is actually connected as one unit to the rest of the lower dash. But, before this lower dash panel can be removed, the black plastic dash panel surrounding the instrument displays must also be removed. The lower part of this panel snaps into the lower dash panel at near the steering wheel.



STEP 1:

At the very bottom of the lower dash panel, locate and remove six (6) 7mm bolt screws.



STEP 2:

Unsnap the fuse panel cover door at the extreme far left of the dash. Locate and remove one (1) 7mm bolt screw hidden behind the fuse box panel cover.



STEP 3:

Locate and remove two (2) 7mm bolt screws that secure the top of the plastic dash panel surrounding the instrument displays.



STEP 4:

Once the 2 screws securing the top of the instrument display panel have been removed, grab the top of the black plastic and pull forward until the top separates from the main dash. Continue pulling at the bottom until the snaps at the bottom unsnap from the lower dash panel.



STEP 5:

Now that the plastic dash panel surrounding the instrument displays has been removed, the lower dash panel can be removed. Open the glove box and pull the top right corner until it begins to unsnap from the dash. Continue to the left side until the dash drops to the floor of the car.



STEP 6:

Once the lower dash panel has been removed, the radio and the screws securing the radio can be seen. Locate and remove two (2) 7mm bolt screws securing the radio (1 on each side). Pull the radio out of the dash. Unplug the black cable and plastic connector plugged into the rear of the radio.