

Chrysler Cirrus | 1996-1999 Car Radio Removal



STEP 1:

The plastic dash panel surrounding the radio must be removed. This dash panel simply unsnaps from the main dash panel. The best way to unsnap this trim dash panel is to insert a small flat head screwdriver or a hook tool between the radio trim dash panel and the softer main dash panel. Slowly and carefully begin to pull the radio trim dash panel out to unsnap.



STEP 2:

The radio is held in with (2) two 10 mm bolts. Remove both and pull the radio to free it from the dash. Unplug both dash wire harnesses that snap into the rear of the radio. Unplug the antenna wire. If your vehicle has the "INFINITY" radio system installed, you will need to unplug the single wire connector attached to the rear of the radio. Pull the radio out of the dash.

