

Isuzu Rodeo | 1999-2000 Car Radio Removal



STEP 1:

Slide out the ashtray. The metal ashtray inside the slide out arm can be pulled out. Pull the metal tray out of the slide out tray. Once the metal tray is removed, a single phillips screw hidden behind the metal tray can now be seen. Locate and remove one (1) phillips screw. (in the photo above, the entire slide out tray is removed for photo clarity.)



STEP 2:

The plastic dash panel around the radio must be removed. Once the screw has been removed in STEP 1 the dash panel can be removed. The dash simply snaps into the body of the dash at the top of the plastic panel. To unsnap the panel, pull the bottom of the plastic panel until it unsnaps from the main body of the dash.



STEP 3:

The radio is held in with (4) four **phillips screws**, two (2) on each side of the radio. Remove all screws. The radio is attached to the pocket below the radio. Pull the entire radio/pocket assembly out of the dash. Unplug the antenna cable from the rear of the radio. Unsnap 1 connector from the rear of the radio. The radio can now be removed.