

Volkswagon Jetta | 1995-1998 Car Radio Removal



STEP 1:

The Volkswagen radio is snapped into the vehicles dash. With the proper tool, known as VW radio removal keys, the VW radio can be pulled forward out of the dash. A clothes hanger can be used instead of actual VW radio removal keys. Cut the clothes hanger and bend 2 pieces in the shape as shown in the photos above.

For more information on how to remove the radio, see the diagram below.




STEP 2:

Pull the radio from the dash. Unplug the antenna cable from the rear of the radio. Unplug the black and brown wire harness connectors from the rear of the radio.

Removing VW Radios Using "U" Shaped Removal Keys

Insert the "U" shaped keys into the holes as shown in the diagram. Coat hangers can be cut and bent into shape for a quick, cheap replacement or alternative when VW keys are not available.



In order for the radio to be removed, clips attached to the side of the radio must be moved inward so the radio can slide out of the dash. Insert the keys and push each key out, away from the radio. The ends of the keys will press into the clips. While pushing the keys outward, pull and the radio should slide forward out of the dash.

